

Offset Reamer Drivers – Technical Guide



## Contents

Offset Reamer Drivers – Technical Guide

Overview	1
Components & Features	2
Assembly Instructions	3
Attach/Detach Reamer – Locking	7
Attach/Detach Reamer – Open	8
Disassembly Instructions	9
Catalogue	13
Nota Bene	14





The Enztec Reamer Drivers allow the reamer to be placed in the incision prior to connection, supporting a Direct Anterior Approach.

These are available, with a traditional locking capture, or novel open capture.

The locking version allows forward and reverse reaming with crossbar reamers.

The open version is for forward reaming only.








## Components & Features

The Enztec Offset Reamer Drivers consist of five components; the Offset Body, Offset Cover, Offset Coupling, Offset Drive Train and Handle

The Offset Coupling is available with a Zimmer, Hudson, or Large AO connection. The Offset Drive Train is available with a traditional locking capture, or novel open capture.

This modularity provides set flexibility as all parts are field changeable.








# Step One – Assembly

### Fit Offset Drive Train

**European Orthopaedics** 




# Step Two – Assembly

### Fit Offset Drive Shaft

Slide the Offset Drive Shaft through the proximal end of the Offset Body.

> Ensure the Offset Drive Shaft and Offset Drive Train are correctly aligned.

Push until you hear an audible click as the Offset Drive Shaft engages into the Offset Drive Train.








# Step Three – Assembly

### Fit Offset Cover







## Step Four – Assembly


### Fit Handle

Slide Handle onto Offset Body.

Ensure the handle securely locks into position by pushing it towards the Offset Body until you hear an audible click.



The Handle can be indexed in 45° increments by depressing the button on top of the handle and rotating to the desired position.







# Attach/Detach Reamer – Locking


### The Enztec Offset Reamer Driver – Locking is compatible with crossbar reamers

Push reamer against the coupling head sleeve.

Twist the reamer in a clockwise direction to lock into the coupling. To detach, pull sleeve away from reamer and twist reamer anticlockwise to remove







Note that if the drill is not attached you may need to hold the protruding end of the Offset Drive Shaft to prevent rotation of the coupling head.






## Attach/Detach Reamer – Open


## The Enztec Offset Reamer Driver – Open is compatible with crossbar reamers


Push reamer into coupling head.

Twist in a clockwise direction to attach.

To detach, twist reamer anticlockwise and remove reamer







Note that if the drill is not attached you may need to hold the protruding end of the Offset Drive Shaft to prevent rotation of the coupling head.






# Step One – Disassembly


### Remove Handle

Depress the button on the top of the handle and slide the handle off the Reamer Driver.





### Remove Offset Drive Shaft









# Step Three – Disassembly

### Remove Offset Cover



# Step Four – Disassembly

### Remove Offset Drive Train









### Pre Cleaning

Cleaning



### Post Cleaning Lubrication



- During manual cleaning, actuate all moving parts to ensure access to all areas.
- Post cleaning, apply lubricant to all joint areas as highlighted, to extend longevity of your device.






# Catalogue

### Offset Reamer Drivers

51.34.1150A	Offset reamer driver – Locking – AO
51.34.1151A	Offset reamer driver – Open – AO
51.34.1169A	Offset reamer driver – Locking – Zimmer
51.34.1170A	Offset reamer driver – Open – Zimmer
51.34.1171A	Offset reamer driver – Locking – Hudson
51.34.1172A	Offset reamer driver – Open – Hudson







# Catalogue

### Replacement Parts


4250-7048	Offset Body
4250-7031	Offset Cover
4250-7012	Handle

#### **OFFSET DRIVE TRAIN**

4250-7035	Open
4250-7036	Locking – Crossbar

#### **OFFSET COUPLING**

4250-7032	Zimmer
4250-7033	Hudson
4250-7034	Large AO







### Nota Bene

A surgeon must always rely on his or her own professional clinical judgement when deciding which products and/or techniques to use on individual patients. Enztec is not dispensing medical advice and recommends that surgeons be trained in orthopaedic surgeries before performing any surgeries.

The information presented is intended to demonstrate the breadth of Enztec product offerings. Always refer to the package insert, product label and/or user instructions before using any Enztec product. Products may not be available in all markets. Product availability is subject to the regulatory or medical practices that govern individual markets. Please contact your Enztec representative if you have any questions about the availability of Enztec products in your area.

Enztec own, use or have applied for the following trademarks or service marks: Enztec.



Enztec Limited 3/17 Print Place Middleton Christchurch 8024 New Zealand

#### Contact:

Enztec Limited P. O. Box 31029, Ilam Christchurch, 8444 New Zealand Ph: + 64 3 348 0203 W: www.enztec.com

#### Distributed by:

Mathys Ltd Bettlach
Robert Mathys Strasse 5
P.O. Box
2544 Bettlach
Switzerland
www.mathysmedical.com

© 2020 Enztec Limited All rights reserved.



